



DELD – Tutorial 2




ECED SVNIT

























Two Level Clipper Circuit


























Zener Diode Clipper Circuits











 Determine the maximum and minimum values of Zener Current.







Voltage across
$$5 \text{ k}\Omega = 120 - 50 = 70 \text{ V}$$

Current through 5 k
$$\Omega$$
, $I = \frac{70 \text{ V}}{5 \text{ k}\Omega} = 14 \text{ mA}$

Load current,
$$I_L = \frac{50 \text{ V}}{10 \text{ k}\Omega} = 5 \text{ mA}$$

Applying Kirchhoff's first law,
$$I = I_L + I_Z$$

$$\therefore \qquad \text{Zener current, } I_Z = I - I_L = 14 - 5 = 9 \text{ mA}$$

Voltage across
$$5 \text{ k}\Omega = 80 - 50 = 30 \text{ V}$$


Current through 5 k
$$\Omega$$
, $I = \frac{30 \text{ V}}{5 \text{ k}\Omega} = 6 \text{ mA}$

Load current,
$$I_L = 5 \text{ mA}$$

Zener current,
$$I_Z = I - I_L = 6 - 5 = 1 \text{ mA}$$





 What value of series resistance is required whe n three 10 W, 10 V, 1000 mA Zener diodes are connected in series across a 45 volts DC power source?





• Determine Va:







- In a CB connection, current amplification factor is 0.9. If the emitter current is 1 mA, determine the value of base current.
- In a CB connection has same emitter current as above. If the emitter is open, the collector current is measured to be 50 μ A. Find the total current. Given α =0.92.



- Determine the values β for 1) α =0.9 2) α =0.98 3) α =0.99
- The collector leakage current in a transistor is 300 μ A in CE arrangement. If now the same transistor is connected in CB arrangement, what will be the leakage current? Given $\beta=120$.



To Be Continued...

